



Fill Casing Section

- 1. Drift eliminators
- 2. Fill kit & fill supports
- 3. Spray nozzles & nozzles grommets
- 4. Spray branches
- 5. Spray branch grommets
- 6. Spray header


Pan Fan Section

- 7. Fan housing & fan snout
- 8. Fan guard
- 9. Motor base adjusting screw
- 10. Strainer
- 11. Make-up valve assembly
- 12. Float ball
- 13. Centrifugal fan assembly(see detailed view)
- 14. Heater
- 15. Low level cut out switch
- 16. Heater thermostat
- 17. Access door & gasket



Centrifugal fan assembly

- A. Centrifugal fan wheel
- B. Fan shaft
- C. Bearing drive end with locking collar
- D. Bearing non-drive end with locking collar
- E. Bearing support
- F. Impervix Fan motor
- G. Drive set
 - Motor sheave & bushing
 - Fan sheave & bushing
 - Belt set



Client contact information

Name _____
 Company _____
 Telephone _____
 Email _____
 Unit model _____
 Serial number _____

Your BAC contact

Name _____
 Telephone _____
 Email _____

Spare parts for cooling tower



This is not an official order form.

Quantities may vary according to the unit type.